




RaptureKit WiFi




<http://rapturekit.local>

Alternate: <http://10.3.141.1>



1. Connect Power



RaptureKit

2. Connect to WiFi

Wireless adapter:



rapturekit.local:8000/wpa_conf

Smartphones may require cellular data disabled to open page

User: **admin**

Password: _____

3. WiFi client configuration


Enter the password for an available WiFi network

Click **Add**, and after the page reloads, click **Connect**



4. Bridge to internet-connected WiFi network

Raspberry Pi Zero W 2



SSH Login:
User: **servant**
Password: _____

PWR

Ethernet adapter:




OR

Wireless adapter:



Stand-alone operation
(no internet):



Ethernet or wireless routed
operation (internet access):

